


FOLDING AWAY INSTRUCTIONS


Lower the legs by pulling out the ring of the slider on legs. Two people should lower two legs at the same time.

BE CAREFUL


Make sure the roof straps, guy ropes and pegs are released/removed before folding the frame away.




MF40S



MF46A



MF58A




SPARE PARTS GUIDE

SPARE PARTS FULL LIST – <https://www.mountainshade.com.au/spares>



MF40SP 012



MF40SP 013




MF40SP 017



MF40SP 012



MF40SP 015



MF40SP 006

SET UP INSTRUCTIONS OF FOLDING PORTABLE MARQUEE



MF40 Steel Range
MF46 Alloy Range

☒ **1.5 x 1.5m**



☒ **2.4 x 2.4m**

☒ **3 x 3m**

☒ **3 x 4.5m**



☒ **3 x 6m**

IMPORTANT:

These folding marquee's are temporary structures only and carry certification of the structural adequacy to be erected as a temporary structure at various sites. These structures should only be erected under the maximum wind speeds stated in the Certificate of Adequacy.



We Ship Australia Wide

88 Latitude Blvd, Thomastown, VIC 3074


www.mountainshade.com.au

Tel: +61 3 94315020

enquiry@mountainshade.com.au

SET UP INSTRUCTIONS

1. Set up the frame on level ground. Two people standing at opposite diagonal ends. Start opening the frame by pulling the legs up and out. Once slightly opened, place the roof over the frame making sure that it is evenly dispersed across the entire frame.



2. In all 4 corners bring the velcro sections of the frame and canopy together making sure the inner velcro part of the canopy lines up neatly with the frame upper leg velcro. Find the centre piece of the canopy top and ensure that it is loosely placed on the centre pole top cap.




3. Each person then positions themselves in the middle of the 2 legs (on opposite sides) and holds the connectors at the middle of the cross bar. Push up and down on connectors, while stepping backward until the frame is fully extended. Work with the mechanism and don't force it.





4. Make sure the roof covers the frame and push up each connector to lock-in and secure the pull ring into the hole.




5. On the inside of the roof canopy wrap the roof velcro straps around the frame and back onto the velcro to keep the canopy secured to the frame.



6. Locate the slider with pull ring at the base of legs. Two people must raise 1 side at the same time by lifting one leg up. Then pull the ring to release the telescopic feet until it lock into the hole. All legs must be set at the same level ideally.




7. Fix the tent to the ground by pegs in the feet, leg weights & guy ropes is required and is your responsibility. It is required to fix the tent by guy ropes included or the Optional Heavy Duty Guy Rope kit for MF58A.



8. Optional Accessories for your Marquee.

- Half wall Clamp **a**
- Marquee to Marquee Clamp **b**
- Gutter **c**



CARE AND MAINTENANCE TIPS:

Wash all parts with mild detergent only and rinse thoroughly. Always pack away only when dry. Lubricate moving parts with silicon spray after wash. If you leave the roof on when folding away, ensure roof is not pinched between crossbars.

MARQUEE DIMENSIONS

